

ESP-2WIRE Controller



2-Wire Benefits Without the Hassle

The ESP-2WIRE Controller and 2W-1 Decoder continue Rain Bird's legacy of the best-in-class 2-wire experience with an approachable platform for projects up to 50 stations. With new Decoder Auto-Address functionality, all decoders connected to the 2-wire path are found and assigned to stations automatically providing significant time savings.

After decoders are programmed, the ESP-2WIRE Controller programs just like the ESP-ME3. With no special wire, wire connector or grounding requirements, contractors can now take advantage of all 2-wire benefits with a familiar platform that's easy to install and program.



50-Station Capacity

The ESP-2WIRE Controller will accommodate up to 50 stations plus master valve without the need to add any expansion modules.



Decoder Auto-Address

The ESP-2WIRE Controller detects decoder addresses connected to the 2-wire path and automatically assigns them to station numbers for significant time savings.



Simple 2-Wire Installation

Standard direct burial wire, standard wire connectors, and no field grounding requirements lowers system cost and makes installation fast and easy.

ESP-2Wire Controller



Easiest and Fastest Decoder Programming Available

- For fastest programming, organize decoders in numerical order by address. The master valve (or station 1 if there is no MV) should be the lowest decoder address in sequence and the highest decoder address should belong to the last station in sequence.
- Label decoders with the station number according to this sequence.
- 3. Install decoders in the field in this order, connecting the 2 blue wires to the 2-wire path and the black wires to the station valve solenoid.
- 4. Turn controller dial to 2-wire settings, follow onscreen prompts and all decoder addresses will be programmed in a matter of seconds.

Program Through the Rain Bird Mobile App with LNK2

- Connect to WiFi for access anywhere in the world or use the embedded Access Point with LNK2 for local access through your mobile device.
- Program all decoder addresses, rearrange addresses, view decoder status and troubleshoot from your mobile device.





Troubleshooting Features

- The Status LED on the back panel of the controller provides real-time insight into what's happening on the 2-wire path
- Each 2W-1 Decoder has a red/green/blue LED for status indication for each individual decoder.

